HOGAR

CEREBRO MIGHTY
SMART HOME HUB

- Avoid pressing hard on the device body, reset button, and connecting ports.
- Make sure you are connected with internet before installation.
- Kindly take care of the distance between the devices as range and performance depend on it.

INSTALLATION

Registering your Cerebro Mighty:
- Install the **Hogar SE** application from respective stores.
- Select signup and agree to the privacy policy.
- Register with your email ID and enter the verification code received in the mail.
- Set the password for your account and sign in with your credentials.

Set Up:
Sign in using the account created → Select **"Create Location"** →Enter **"Location Name"** and your home address (It will automatically take your current location using the device (mobile/tablet) GPS location → Create rooms if you want to add more rooms apart from the default room options.

App Configuration:
- Cerebro Mighty needs to be plugged in with 230V power source. To reset Cerebro Mighty before adding, **press and hold** the reset button for **5 seconds**, the **LED** blinks continuously indicating a successful reset process (refer manual). Navigate to **"Rooms"** → Select **"+"** on the top right corner → Select **"Hub"** and then **"Gateway"**. → Make sure the device is reset and **LED** is in blinking state. → In the App confirm with the **LED** indication checkbox and select **"Next"**.

- The App will scan for the gateway, add the device to the account, rename it, and add it to the desired room. Cerebro

DESCRIPTION

Cerebro Mighty is the processing unit for all Zigbee connected devices used for home automation. It can connect with 60+ Zigbee devices and control them through the Hogar SE App.

PLUG AND PLAY   **MULTI PROTOCOL**   **SECURE SHELL**

APP CONTROL   **SEAMLESS CONNECTIVITY**

APP INFORMATION

Cerebro Mighty supports **Hogar SE** App and works seamlessly by integrating with all other Smart Home Devices. Please refer to the manual for setting up **Rooms**, **Floors**, **Devices** and **Automate/Schedule** them to control your smart home.

WARRANTY & ENQUIRY

Hogar provides a limited warranty of 18 months on every product
For Orders/Details, kindly reach out to us at
info@hogarcontrols.com

SPECIFICATIONS

Operating Voltage	AC 110 –230 V 50–60 Hz
Internet Connectivity	WIFI 802.11
Wireless Protocol	Zigbee
No. of Devices for Connectivity	60+
Range	30 M indoor, 50 M outdoor
CPU	ARM Cortex M3 MCU
RAM	2 MB SDRAM
ROM	4 MB flash
Encryption Level	WAP/WAP2 supported
Operating Temperature	–10° to 40° C
Relative Humidity	8% – 80% RH
Dimension	56x52x30 mm